



OW 4002 Oil-Water-Cooling Unit

Specification and User Manual Version 2.1

Laird Thermal Systems.
Prumyslová 497
462 11 Liberec
Czech Republic

Phone: +420 488 575 111

www.lairdthermal.com

Any information furnished by Laird and its agents, whether in specifications, data sheets, product catalogues or otherwise, is believed to be (but is not warranted as being) accurate and reliable, is provided for information only and does not form part of any contract with Laird. All specifications are subject to change without notice. Laird assumes no responsibility and disclaims all liability for losses or damages resulting from use of or reliance on this information. All Laird products are sold subject to the Laird Terms and Conditions of sale (including Laird's limited warranty) in effect from time to time, a copy of which will be furnished upon request.

© Copyright 2020 Laird Thermal Systems, Inc. All rights reserved. Laird™, the Laird Ring Logo, and Laird Thermal Systems™ are trademarks or registered trademarks of Laird Limited or its subsidiaries.

Table of Contents

Revision History	5
1. About this Manual	6
Terms of Guarantee	6
Contact Information	7
2. Product Identification	8
Unit Specifications	8
Identification Plate	8
3. Safety Regulations	9
Hazard classes	9
Safety Symbols	9
Hints for Safe Operation	10
Prevent Hazards	10
Hints Regarding the Electrical Equipment	10
Environmental Issues	11
Protective Clothing	11
Safety Equipment	11
Safety and Signalling Equipment included in the Unit	11
Guards	12
In Case of Accidents	12
4. Product Description	13
Intended Use	13
Non-Conformity with the Intended Use	13
Unit Components	14
Specifications	15
Setting-up Requirements	16
Installation Location	16
Environmental Conditions	16
Infrastructure	16
5. Transport	17
Safety Indications for Transportation and Setting-up	17
Transportation of the Unit	17
Unpacking	17
6. Initial Operation	18
Safety Indications Related to Initial Operation	18
Setting to Work	18
Installation location	18
Cooling Circuit Connection and Filling	18
Connection the Cooling hoses	18
Connection the Cooling hoses	19
Connecting the unit electrically	20

Carrying out Setting to Work	21
Daily Start-up	22
Setting-to-Work after Storage	22
7. Controlling the Unit	23
Safety Indications for Controlling the Unit.....	23
Switching on the Unit	23
Switching off the Unit	23
Settings	24
Pressure Setting on the Angle-type Safety Valve	24
Setting the Thermostat.....	25
8. Disruptions	26
Disruption in Operation	26
Trouble Shooting.....	26
9. Maintenance and Cleaning.....	27
Maintenance Schedule.....	27
Refilling of Coolant	27
Cleaning of Unit Casing	27
10. Repair	28
11. Dismounting, Disposal, Storage.....	29
Temporary Placing out of Operation	29
Re-packaging of the unit	29
Storing the Unit	29
Disposal.....	29
Disposal of Operating Materials	30
Return of the unit to Laird Thermal Systems	30
12. Wear Parts and Spare Parts.....	31
Addendum.....	33
Performance chart.....	33
Flow scheme	34
Wiring diagram	35

Revision History

REV	DATE	DESCRIPTION	NAME	Page
2.1	09/30/20	Document template updated to LTS format, Updated copyright statement	Maria Mjalgard	
2.0	03/12/20	New Manual	Henrik Olsson	
1.0	11/29/13	First version	Edom/Pfeiffer	

1. About this Manual

This Operational Manual addresses the needs of the user of the unit. Its intention is to allow the safe operation of the unit. Thus, it should be read carefully and be kept in a space accessible for the users of the unit at any time.

All chapters of this Operation Manual can be read independently and thus can be used for look-up purposes.

Terms of Guarantee

General sale and delivery terms of Laird Thermal Systems apply. The buyer accepts these terms, at the latest when signing the contract of purchase.

The particular terms of guarantee and duration of guarantee of the unit in question can be taken from the contract documents as well as from the order confirmation.

Warranty claims and liability are excluded in case of one of the following situations:

- Use of the unit in an unintended way
- Inaccurate installation, putting into service, operation, repair or maintenance of the product by people that are not fully authorized
- Use of the product despite of defect, wrongly implemented or non-functional safety devices or protective gear
- Unauthorized or forbidden modifications by the user concerning the electrical equipment of the unit
- Unauthorized or forbidden modifications by the user concerning the mechanical structure of the unit
- Unauthorized or forbidden modifications by the user concerning the operating parameters
- Use of unauthorized tools
- Use of unauthorized operating supplies
- Exceedance of mandatory maintenance intervals
- Cases of disaster caused by foreign matter influence or act of nature beyond control

NOTE

Any form of unintended use of the unit and any structural change caused by the user without prior authorization in written form by Laird Thermal Systems will lead to the termination of warranty as well the termination of the declaration of conformation and will free Laird Thermal Systems from product liability. This concern includes safety devices as well.

In case of authorized changes or when adding optional equipment, it is the sole responsibility of the customer to assure the accurate implementation of the required safety devices.

Contact Information

If you have questions with respect to this unit please use the contact information given below. Always communicate the following:

- Your name and address
- Name of contact at your address
- Product data as on identification plate: Type of unit, serial number and year of manufacture

Company contact:

Laird Thermal Systems
Prumyslová 497
462 11 Liberec

Czech Republic

2. Product Identification

Unit Specifications

Manufacturer	Laird s.r.o.
Type of product	Oil-Water cooler
Type of unit	OW 4002
Article number	1155.00

Table 1: Unit specifications

Identification Plate

The identification plate is attached on the top of the coolant container below the unit cover.




Fig. 1: Position of identification plate

1	Identification plate
---	----------------------




Fig. 2: Unit specific identification plate

1	Unit type	2	Article number
3	Serial number	4	Electrical specification
5	Date of manufacture		

3. Safety Regulations

Hazard classes

In this document safety instructions are using standardized representation and symbols. Depending on the probability of their incidence and the severances of consequences three hazard classes are used.



DANGER



Reference to direct danger for humans.

Inobservance will lead to irreversible injuries or death.



CAUTION

Reference to noticeable danger for humans or possible damage to property.

Inobservance may lead to reversible injuries or to damage to property.

Safety Symbols

In this Operation Manual concrete safety instructions are given in order to point out unpreventable residual risks when operating the unit. These risks include danger for

- Human beings
- The unit and other equipment
- The environment

The safety symbols used in this manual are indicated below. The main reason for their use is to point the reader to the safety instruction given in the text field beside.



Symbol	Meaning
	Warning with respect to general danger or damage to property
	Warning with respect to electrical hazard

Table 2: Warning signs



Symbol	Meaning
	This symbol indicates the requirement of wearing safety gloves
	This symbol indicates that disconnecting from mains is required.

Table 3: Signs giving orders

Hints for Safe Operation

NOTE

Conduct inspections on a regular time base!

This will ensure that the appropriate measures will be carried out indeed.

The unit is operation save. It was built according to the state-of-the-art.

Despite this the unit could cause hazards if it

- is used in a way it was not intended for
- is used improperly
- is operated under unsuitable conditions

Prevent Hazards

Hazards can be prevented by safety-conscious and anticipatory behavior of staff.

Everybody working with the unit should keep the following in mind:

- Make this Operation Manual available for everybody at the operational location of the unit in a complete and perfectly readable form!
- Use the unit exclusively for what it was intended!
- The unit must be operational and error free. Check the condition of the unit before working with it and within a regular time frame!
- Make sure that nobody can injure himself by any part of the unit!
- Any disruption or recognizable change concerning the unit should be reported to the responsible person!
- Stick to the accident prevention regulations as well as any regional regulations!

Hints Regarding the Electrical Equipment



DANGER



Danger to life through electrical shock when working on the electrical equipment of the unit!

- Switch off the unit before starting your work!
- Disconnect the unit from mains by pulling the mains plug!
- Verify that the installation is dead (volt-free)!
- Carry out earthing or short circuiting!

When working on electrical installations the following principles should be observed:

- Works on the electrical installations may only be accomplished by qualified electrical staff!
- When connecting electrical equipment to mains regional regulations must be observed. Be aware of the information in the wiring diagram!
- The unit is powered by electricity. Electrical shock hazard exists, if the electrical installations are defective or the insulation fails during operation.
- When switched off the unit is not disconnected from mains. This is only the case when the mains plug is pulled.
- Any changes regarding the control elements of the unit can have an influence on the safe operation. All intended changes must be authorized by the manufacturer.
- After the implementation of a change the safeguard operations must be verified.
- No unauthorized changes on the unit are allowed. All intended changes must be authorized by the manufacturer.

Environmental Issues

Environmentally conscious and anticipatory behavior of staff avoids environmentally hazardous impacts.


The following principles apply for environmentally conscious behavior:

- Environmentally hazardous substances must not get into the ground or the drains. They should be kept in appropriate containers.
- Environmentally hazardous substances must be fed to utilization or disposal according to regional regulations.

When dealing with operating supplies always keep aware of the safety data sheet of the corresponding manufacturer.

Protective Clothing

When doing a job that leads to contact of the skin with the coolant (e.g. filling-up of the coolant container):

	Wear safety gloves made of PVC, neoprene or nitrile rubber
---	--

Safety Equipment

NOTE

The safety equipment listed below must be integrated in the local control environment by the customer, unless otherwise noted. These works must be carried out only by trained experts. All required information can be taken from the wiring diagram shown in the addendum.

Safety equipment must not be modified, removed or taken out of operation. All parts of the safety equipment must be accessible at all times.

Safety and Signalling Equipment included in the Unit

- The unit is equipped with safety equipment at critical spots:
- The filling level of the coolant container is indicated in an inspection glass.
- The circulated oil amount is controlled by a flow control device (flow switch) that must be integrated in the potential-free safety circuit of the device that is to be cooled.
- The oil temperature is controlled by a thermostat. When the oil temperature exceeds the maximum setpoint this is indicated by the potential-free safety circuit.
- The maximum pump pressure is limited by an angle-type safety valve that bypasses the oil stream when the pressure pre-set is exceeded.




Figure 3: Safety equipment

1	Thermostat	2	Flow control device (flow switch)
3	Angle-type safety valve	4	Inspection glass, level indicator

Guards

Direct access to hazardous parts or areas of the unit is restricted by the unit cover. The cover may only be removed for maintenance or repair works and shall be replaced prior to taking the unit back to operation. The cover is fixed by four screws which can be unscrewed using a metric AF10 wrench.

In Case of Accidents

Should you or another person be injured when working with the unit:

- Stay calm!
- Give first aid!
- Call the company's first-aider without exception!

First aid at accidents with oil

The unit employs oil as a coolant in a closed-loop configuration. In case of damage oil can leak from the circuit and cause hazards.

- Long term or repeated contact with skin without appropriate cleaning may obstruct the skin pores and may lead to irregularities as oil acne or folliculitis.

When exposed to oil always observe the safety data sheet of the manufacturer.

4. Product Description

Intended Use

The oil-water cooler OW 4002 is used for the cooling of an oil circuit. Oil circulates between the cooling unit and the device to be cooled. The oil is re-cooled by a water-cooled heat exchanger. The maximum cooling capacity depends on the water temperature. See addendum.

The unit is exclusively intended for use in industrial and commercial environments.

The intended use also includes the observance and following of all hints given in this Operation Manual.

Non-Conformity with the Intended Use

Operation of the unit under improper operational conditions is not permitted, since otherwise the operation safety cannot be granted.

When using the unit in a way not compliant with the intended use, hazardous situations may occur.

Operation of the unit is not permitted under the following conditions:

- The unit is used for a purpose other than the one it is intended for.
- The unit or parts of it are damaged, the electrical installation is not correct or the insulation is broken.
- Protective or safety equipment is not functional or defect, improperly installed or missing.
- The unit is not working properly.
- The unit was modified without authorization or modified in a way that is not permitted.
- Controlling devices were modified in a way that is not permitted.
- Operational parameters were changed in a way that is not permitted.
- Operation in areas exposed to explosion hazards.
- Operation with cooling media not according to specification.
- Use of unauthorized tools.
- Exceedance of the compulsory maintenance intervals.

NOTE

The manufacturer is not liable for damage occurring when using the unit in a way it was not intended for. When using the unit in a way it was not intended for, the manufacturer's warranty given by Laird Thermal Systems will expire.

Unit Components

Additional information can be retrieved from the flow scheme shown in the addendum. The unit consists of the following main components:




Figure 4: Main components

1	Cooling circuit	2	Coolant container
3	Sheet-metal hood		

Cooling Circuit

In the cooling circuit the coolant (i.e. the oil) is driven by the pump to the device that is to be cooled and back via the return flow. The heat is dissipated into the water circuit by a water-cooled heat exchanger. Exceedance of the maximum pump pressure is prevented by a bypass circuit. The oil temperature is controlled by an electronic thermostat. Oil throughput is controlled by a flow control device.

Specifications

Dimensions and weight

Length:	650 mm
Width:	350 mm
Height:	550 mm
Weight:	45 kg (empty)
Coolant capacity:	23 liters (Shell Diala S4-ZXI)

Table 4: Dimensions and weight

Performance data

Cooling capacity:	4000 Watts
Pump capacity:	> 22 lpm at 3.5 bar
Mains voltage:	230 VAC ± 10% 50/60 Hz

Table 5: Performance data

Environmental conditions

Operating temperature:	+5°C ... +40°C
Storage temperature:	-25°C ... +70°C
Relative humidity:	20% ... 80%

Table 6: Environmental conditions

Settings

Flow control device	17.0 ± 0.3 lpm
Thermostat	55 ± 3 °C
Maximum pressure	9.0 +0.5/-0.2 bar

Table 7: Settings

Setting-up Requirements

Installation Location

- The location must be even.
- When choosing the installation location, the following must be kept in mind: out- and in- flow connections must be easily accessible and all hoses must be installed without sharp bends.

Environmental Conditions



CAUTION

Risk of damage through unsuitable environmental conditions.

Damage to property and corrosion damage may result and are not covered by manufacturer's liability.

- The unit is only authorized for use in indoor environments.
- The unit must not be stored or operated in aggressive, humid environments.
- The unit must not be stored or operated outdoor.

Pay attention to the environmental conditions as given in the specifications on page [15](#).

Infrastructure

The following infrastructure is required for connecting the unit:

Parameter	Rated value
Operating voltage	230 VAC

Table 8: Required infrastructure

5. Transport

Safety Indications for Transportation and Setting-up



CAUTION

Risk of injury by lifting the unit!

The weight of the unit is more than 50 kg.

- Do not lift the unit manually!
- Always use proper auxiliary means such as a forklift or a jack lift!



CAUTION

Risk of damage by improper transportation!

- Transport the unit in upright position.
- Do not tilt the unit or expose it to impacts.

Transportation of the Unit

The unit is delivered wrapped in foil on a transportable pallet. Leave the unit on the pallet until bringing it into service. Use a forklift or jacklift for transportation to the installation location.

Unpacking

Remove the foil before setting up the unit.

Inspect the unit with regard to:

- Damage caused by transportation
- Completeness of delivery

Lift the unit with a forklift or jack lift off the transportable pallet.

Dispose of the packaging material in accordance with regional regulations

NOTE

Laird Thermal Systems advises to keep the transportable pallet for later transportation of the unit.

6. Initial Operation

Safety Indications Related to Initial Operation



CAUTION

Danger of malfunction caused by faulty connections during initial operation!

Before switching on the unit make sure that:

- All safety equipment of the unit is implemented and functional.
- All connections were properly made.
- Nobody is endangered by the start-up of the unit.

Please follow the rules in chapter Safety Regulations on page [9](#).

Setting to Work

NOTE

In case of storage of the unit at temperatures lower than 5°C or higher than 40°C for longer periods please wait 3 hours prior to initial operation to allow for temperature adjustment.

Installation location

- The location must be even.
- When choosing the installation location, the following must be kept in mind: coolant inlet and coolant outlet connections must be easily accessible and all hoses must be installed without sharp bends.

Cooling Circuit Connection and Filling



CAUTION

Risk of damage by using improper cooling hoses!

This may lead to damage to persons, damage to the unit or corrosion damage.

- When choosing cooling hoses pay attention to sufficient burst strength and compatibility with coolant!
- Only use cooling hoses without any signs of damage!

Connection the Cooling hoses

NOTE

Risk of damage by using improper or faulty coolant hoses!

This may lead to damage to persons, damage to property or corrosion damage.

- When choosing coolant hoses pay attention to sufficient burst strength and compatibility with coolant.
- Only use coolant hoses without any signs of damage.

When connecting the coolant hoses pay attention to flow direction. Follow the documentation released by the manufacturer of the unit to be cooled.

The coolant hoses are connected to the unit by means of screw-in connectors. Coolant inlet and coolant outlet are labeled with respective symbols.




Figure 12: Labeling of coolant inlet and coolant outlet

Procedure

- Remove the protection caps from the coolant inlet and coolant outlet connections of the unit.
- Connect an appropriate coolant hose to the coolant inlet and coolant outlet respectively.
- Screw the connection screws for connecting the coolant hoses to the unit using the spanner for countering, in order to avoid the hydraulic line from being destroyed.
- Connect the coolant hoses to the corresponding connections of the unit to be cooled.

The coolant hoses are now connected to the unit.

Connection the Cooling hoses

The cooling water hoses are connected to the unit by means of hose nipples. Cooling water inlet and cooling water outlet are labeled with respective symbols.




Figure 13: Labeling of cooling water inlet and cooling water outlet

Connecting the cooling water hoses

Procedure

- Remove the protection caps from the cooling water inlet and cooling water outlet connections of the unit.
- Connect an appropriate cooling water hose to the cooling water inlet and cooling water outlet respectively.
- Secure the hoses with a hose clamps.
- Tighten the hose clamps.
- Screw the connection screws for connecting the cooling water hoses to the unit using the water pump pliers.
- Connect the unit to the available water supply.

The cooling water hoses are now connected to the unit.

NOTE

When operating the unit make sure only to use the operation coolant container cap. This cap allows for pressure equilibrium in the cooling system (breathing). Save the transportation cap for later transportation purposes (e.g. when sending the unit back for repair).

Connecting the unit electrically



DANGER



Work on electrical installations may be carried out by trained and authorized electricians only.

- Switch off the unit before starting your work.
- Disconnect the unit from mains by pulling the mains plug.
- Secure the unit against being switched on again.
- Verify that the unit is disconnected.
- Carry out earthing and short circuiting.
- Keep unauthorized persons away from the working area.

NOTE

Risk of damage through improper connections!

Improper integration of the unit into the safety circuit of the device to be cooled will lead to the inoperativeness of the safety equipment included in the unit.

- Incorporate all required connections according to the wiring diagram shown in the addendum.
- Ensure that all connected safety equipment is properly functioning.
- All tasks should be carried out only by expert staff.

NOTE

The electrical connection as well as the integration into the safety circuit of the device to be cooled are the customer's responsibility and must be accomplished by expert staff.

Information required can be taken from the technical specifications listed in the wiring diagram available in the addendum.




Figure 6: Mounting position of the terminal box

After implementing the mains cable connect the unit to mains by inserting the mains plug.

Carrying out Setting to Work



CAUTION

Lack of coolant may destroy the pump!

- Operate the unit only when the filling level of the coolant container is correct!
- Check the filling level of the coolant container regularly!

After connecting the cooling circuit, filling the coolant container and finishing the electrical connection follow the steps below for the setting-to-work of the unit:

- 1) Open the stop valve.
- 2) Let the unit run for about 1 minute in order to de-aerate the pump.
- 3) Switch off the unit.
- 4) Close the stop valve.
- 5) Let the unit run for about 10 minutes in order to fill and de-aerate the cooling circuit.
- 6) Switch off the unit.
- 7) Check the filling level using the inspection glass. Fill up oil, if required, until a liquid level in the center of the inspection glass. Use a funnel in order not to moisten any current-carrying components with oil.
- 8) Remount the unit cover.
- 9) Switch on the unit again and check the compliance with the operational parameters.



DANGER



Danger to life by electrical shock caused by improperly mounted grounding washer!

- Mount the grounding washer at the position of one of the four screws securing the unit cover!
- Make sure that the screws are properly tightened!

This is to make sure that the grounding washer cannot get loose by vibrations during operation which could lead to the situation of the unit cover carrying current.



Figure 7: Mounting position of the needle valve

The unit is ready for use.

Daily Start-up

Switch on the unit about 1 minute prior to using the equipment that is to be cooled.

Setting-to-Work after Storage

Setting-to-work after storage will have to follow the same procedures as required for initial operation (see chapter [6](#)).

7. Controlling the Unit

The unit is controlled using the controls of the equipment that is to be cooled.

All alarm and error signaling is only indicated on the control panel of the equipment that is to be cooled.

Safety Indications for Controlling the Unit



CAUTION

Lack of coolant may destroy the pump!

- Operate the unit only when the oil filling indication on the coolant container is correct!
- Check the oil filling indication regularly!

Also pay attention to the hints given in the chapter Safety indications on page [9](#).

Switching on the Unit

- The unit is ready for switching on.
- 1) Switch on the unit about 1 minute prior to operation of the device to be cooled using the appropriate control of that device.
- 2) Check the compliance with the required operational data according to the specifications
- ⇒ The unit is running.

Switching off the Unit

- 1) Switch off the unit using the control of the device to be cooled.
- 2) Close all valves that may exist along the hoses running to and from the unit
- ⇒ The unit is out of operation.

Settings

The angle-type safety valve and the thermostat are set to the specified values by the manufacturer. Should any modification be required, please follow the steps indicated below.

Pressure Setting on the Angle-type Safety Valve

NOTE

A small amount of oil may leak from the valve.

- The unit is switched off.
 - 1) Carry out pressure adjustment with hexagonal wrench key.
 - 2) Turning clockwise increases pressure, turning anticlockwise decreases pressure.
 - 3) The valves can be set when backpressure prevails or when medium is flowing through the valve.
 - 4) The setting can be secured by means of a seal.
 - 5) Check the maximum pressure again and repeat the setting, if necessary.
- ⇒ The maximum pressure is now set.




Fig 5: Angle-type safety valve

1	Adjusting screw	2	Hexagonal wrench key No 10
---	-----------------	---	----------------------------

Setting the Thermostat




Fig: 6 Thermostat

1	Knob of thermostat
---	--------------------

Increase the temperature setpoint

- 1) Turn the knob clockwise.
- ⇒ The switch-off temperature is set to a higher value.

Decrease the temperature setpoint

- 2) Turn the knob counter-clockwise.
- ⇒ The switch-off temperature is set to a lower value.

8. Disruptions

Disruption in Operation

The most common reason for disrupting operation of the unit is improper maintenance. Maintenance should be carried out regularly according to the maintenance intervals defined in chapter 9.

In case of disruption start with checking the following:

- Coolant polluted?
- Low coolant contents because of leakage, evaporation or an extended cooling circuit with long hoses?

More help can be found in the following paragraph.

In case you do not succeed in identifying the problem cause by means of this manual please contact the service department of Laird Thermal Systems.

Trouble Shooting

For trouble shooting you may rely on the following:

- Alarm signaling within the safety circuit of the device to be cooled
- Wiring diagram
- Flow scheme
- Trouble shooting table given below

Problem	Possible reason	Countermeasure
The unit does not start	Mains cable plugged in?	Insert mains plug→
The unit is running, but cooling capacity is not available or too low	External hoses sharply bent?	Pay attention to smooth bends, when hoses are connected
	Coolant hoses connected?	Connect hoses considering flow direction→
	Is there flow in cooling circuit?	Flow is signaled potential-free by the safety equipment of the unit and can be visualized in the range of controls of the device to be cooled.
	Flow of water circuit	Does the facility water circuit have flow? Check facility system.
	Water temp too high	Check facility water temperature is correct.
	Contents in coolant container low	Refill coolant

Table 9: Trouble shooting list

9. Maintenance and Cleaning

Diligent maintenance is the prime factor for assuring an error-free and efficient operation of the unit. Operating personnel can perform these tasks when properly trained.

Maintenance Schedule

Device	Activity	Interval	Criteria	Tools	Performer
Coolant container	Check filling	Weekly	Coolant indication in the center of inspection glass	Funnel, measuring cup	Operating personnel
Coolant quality	Inspect visually	Weekly	Absence of cloudiness or floating particles	Inspection glass on coolant container	Operating personnel

Table 10: Maintenance schedule

Refilling of Coolant

Since the cooling circuit is an open circuit, evaporation of coolant may occur. Thus the filling level of the coolant container has to be checked regularly, and coolant might have to be refilled as described in chapter 6.

Cleaning of Unit Casing



CAUTION

Risk of damage due to the use of improper cleansing material!

When using aggressive or abrasive cleaning agents, corrosion may occur as result of a damaged paint film.

- For cleaning the device casing only use mild cleaning agents (e.g. dish washing detergents)!
- Use clean and lint free cloth for cleaning!

Regularly remove dirt from the casing of the unit to prevent corrosion damage and clogging of the air grids. Pay attention that all the plates at the unit are always clean and legible.

10. Repair

NOTE

Do not carry out any repair work on the unit. Send the unit back to Laird Thermal Systems service department, contact us via lairdthermal.com/contact

11. Dismounting, Disposal, Storage

Temporary Placing out of Operation

For placing the unit out of operation for maintenance or repair follows the steps below:

- 1) Switch off the unit.
- 2) Close all valves that may be incorporated in the cooling circuit.
- 3) Disconnect all hoses to and from the unit.
- 4) Place a collection container of enough volume (23 liters minimum) close to the drain screw.
- 5) Loosen the drain screw with a 10 mm Allen key and remove it.
- 6) Let the coolant container run empty into the collection container. To empty the coolant container completely the unit must be tilted.

NOTE

The coolant has to be collected and disposed of according to applicable regulations.

- 7) Re-attach the drain screw and clean the unit.

⇒ The unit is placed out of operation.

Re-packaging of the unit

In order to prevent spilling of residual coolant from the coolant container during transport the transport cap must be attached.

- The unit has been switched off, emptied (see chapter [11](#)) and the unit cover has been removed.

- 1) Remove the operation cap from the coolant container.
- 2) Attach the transport cap.
- 3) Remount the unit cover.
- 4) Put the protection caps on the hose clamps.
- 5) Lift the unit with a forklift or jacklift and place the transportable pallet under it.
- 6) Enclose the unit including the transportable pallet with shrinking foil and shrink the foil tight.

⇒ The unit is ready for transportation.

Storing the Unit

The storage area must be even and the unit should not stand on an edge or other obstructive object.

The environmental conditions for storage of the unit or parts of it can be found in the specification paragraph in chapter [4](#).

Disposal

The unit was manufactured mainly from recyclable material.

Make sure the components of the unit end up at a qualified company for disposal and recycling.

Contact Laird Thermal Systems for take back of end-of-life units or ask a company destined for disposal and recycling.

Disposal of Operating Materials

The operating materials of the unit can be hazardous to the environment and to health.

Make sure the operating materials are disposed of or recycled according to local regulations.

Also, the safety specifications of the coolant manufacturer must be obeyed.

Return of the unit to Laird Thermal Systems

NOTE

Declaration of decontamination

Before re-shipment of the unit a declaration of decontamination must be sent to Laird Thermal Systems.

12. Wear Parts and Spare Parts

Spare parts must comply with the technical specifications defined by Laird Thermal Systems. Original Laird Thermal Systems parts are subject to strict obligations and fulfill these requirements.

Laird Thermal Systems does not provide warranty service in case of damages caused by the use of spare parts made by manufacturers other than Laird Thermal Systems.

NOTE

Identification data concerning the unit and spare parts

The type of unit and the article number can be found on the identification plate of the unit. The corresponding numbers shown in drawings 12 and 13 as well as the part description are listed in the spare part list (table 11).

Please direct your inquiries and orders to Laird Thermal Systems (contact see page [7](#)) with the following detailed information:

- Type of unit
- Article number
- Serial number
- Part description
- Quantity
- Shipping detail





Fig 7: Spare part overview part 1

Table 11: Spare parts

Pos.	Qty	Description	Article No.
1	1	Motor pump unit KA1-26-230-2	95205237.00
2	1	Motor capacitor	95290735.00
3	1	Angle-type safety valve	387002608
4	1	Flow control FW1	95140568.00
5	1	Control head for flow switch	95140567.00
6	1	Temperature controller water 25-65°C	95100101.00
7	1	Thermostat AMFS-13	95160001.00
8	1	Inspection glass	93300201.00
9	1	Filler neck	95169901.00
10	1	Filter/strainer 125µm	95169901.00


Addendum

Performance chart



Cooling capacity versus difference between entering water and supplied coolant temperatures

Flow scheme



Item	Designation	Item	Designation
1	Water outlet (hose nipple)	8	Pump with motor
2	Oil inlet (screw in con. M26x1,5)	9	Relief valve
3	Water inlet (hose nipple)	10	Thermostat / Oil temperature
4	Oil outlet (screw in con. M26x1,5)	11	Evaporator
5	Thermal switch	12	Flow controller
6	Throttle valve	13	Level indicator
7	Filter		

Wiring diagram

